


HE AV Extendible inserts

500V 16A 24+ 

Inserts


Hoods/Housings: size 24B bulkhead mounted housings.
For the HEAV extendible inserts assembly instructions pls see the 09-13 page

Male, Screw terminal




Size	Description	Designation	Order No.
24B	left hand version	HE-024-M.AV.L	122 024 011 0101
24B	right hand version	HE-024-M.AV.R	122 024 011 0102

Left hand version



Right hand version




Female, Screw terminal




Size	Description	Designation	Order No.
24B	left hand version	HE-024-F.AV.L	122 024 021 0101
24B	right hand version	HE-024-F.AV.R	122 024 021 0102

Left hand version



Right hand version




Male, Quick-in




Size	Description	Designation	Order No.
24B	left hand version	HE-024-MQ.AV.L	122 024 001 0001
24B	right hand version	HE-024-MQ.AV.R	122 024 001 0002


Left hand version



Right hand version




Female, Quick-in



Size	Description	Designation	Order No.
24B	left hand version	HE-024-FQ.AV.L	122 024 002 0001
24B	right hand version	HE-024-FQ.AV.R	122 024 002 0002

Left hand version



Right hand version

