


HV16B Metal hoods/housings
- for high voltage inserts(HVE Series)

Degree of protection: IP65

Surface mounted housings




Thread	Designation	Order No.
M25	HV16B-SF-4B-M25	124 016 230 1003
2M25	HV16B-SF-4B-2M25	124 016 230 1023
PG21	HV16B-SF-4B-PG21	124 016 230 1011
2PG21	HV16B-SF-4B-2PG21	124 016 230 1031
with plastic cover		
M25	HV16B-SF-4B-CV-M25	124 016 270 1003
2M25	HV16B-SF-4B-CV-2M25	124 016 270 1023
PG21	HV16B-SF-4B-CV-PG21	124 016 270 1011
2PG21	HV16B-SF-4B-CV-2PG21	124 016 270 1031
with metal cover		
M25	HV16B-SF-4B-MCV-M25	124 016 270 1103
2M25	HV16B-SF-4B-MCV-2M25	124 016 270 1123
PG21	HV16B-SF-4B-MCV-PG21	124 016 270 1111
2PG21	HV16B-SF-4B-MCV-2PG21	124 016 270 1131



Surface mounted housings, high construction




Thread	Designation	Order No.
M32	HV16B-SFH-4B-M32	124 016 230 5004
2M32	HV16B-SFH-4B-2M32	124 016 230 5024
PG21	HV16B-SFH-4B-PG21	124 016 230 5011
2PG21	HV16B-SFH-4B-2PG21	124 016 230 5031
PG29	HV16B-SFH-4B-PG29	124 016 230 5012
2PG29	HV16B-SFH-4B-2PG29	124 016 230 5032
with plastic cover		
M32	HV16B-SFH-4B-CV-M32	124 016 270 5004
2M32	HV16B-SFH-4B-CV-2M32	124 016 270 5024
PG21	HV16B-SFH-4B-CV-PG21	124 016 270 5011
2PG21	HV16B-SFH-4B-CV-2PG21	124 016 270 5031
PG29	HV16B-SFH-4B-CV-PG29	124 016 270 5012
2PG29	HV16B-SFH-4B-CV-2PG29	124 016 270 5032
with metal cover		
M32	HV16B-SFH-4B-MCV-M32	124 016 270 5104
2M32	HV16B-SFH-4B-MCV-2M32	124 016 270 5124
PG21	HV16B-SFH-4B-MCV-PG21	124 016 270 5111
2PG21	HV16B-SFH-4B-MCV-2PG21	124 016 270 5131
PG29	HV16B-SFH-4B-MCV-PG29	124 016 270 5112
2PG29	HV16B-SFH-4B-MCV-2PG29	124 016 270 5132



Protection covers, metal



Connect way	Applications	Designation	Order No.
	for hoods	H16B-MCV-4B/1S	111 016 030 8103
	for housings, without sealing	H16B-MCV-4B/2	111 016 030 8102




Protection covers, metal



Connect way	Applications	Designation	Order No.
	for hoods	H16B-MCV-2L/ SC.1S	111 016 041 8101
	or housings	H16B-MCV-2L/ SC.2	111 016 041 8102

Please refer to page 15-02 for choosing proper model of lock.



Please refer to page 15-02 for choosing proper model of lock.